



TUBE PLAYER

User Manual

Thank you for buying a P&P Amplification product.

Please read this user manual before using the pedal for the first time use.

Important : Please always disconnect power supply after using.
Please use 9 or 12v power supply, 400mA minimum, with appropriate polarity (negative in center).

Description du produit :



- | | |
|--------------------------|-----------------|
| 1 : Input | 6 : volume knob |
| 2 : Output | 7 : Footswitch |
| 3 : Gain knob | 8 : DC in |
| 4 : Tone knob | 9 : Tubes |
| 5 : Treeble Boost switch | |

Guide d'utilisation :

1. Plug your guitar in input (1)
2. Plug your amp in output (2)
3. Plug your power supply (8), wait a few seconds
4. Press the footswitch (7) to active the effect

5. Use the three knobs to adjust the sound (3) (4) (5) You can active the Treeble Boost too (5)

The Treeble Boost only works when gain knob is below the two thirds of its possibility.

Tube Player is also a standalone preamp: you can plug it directly in the fx loop of your amp or in a power amp

Tubes replacement :

Tube Player works with two electronic tubes ecc82, better known as 12au7.

These tubes may become worn with time. If your pedal doesn't work at all, you may have to replace it.

To do that, start to unplug the dc cable. Unplug tubes and replace them by new ones. Be careful : it's fragile.

You can replace origin tubes by others from different brand. You just have to insure that the type is ecc82 (12au7).

Mentions légales :

Plug&Play Amplification ®
All rights reserved

57 rue du Moulinet
59310 COUTICHES
FRANCE

European union safety compliant product **CE**
2 years Warranty

Do not bin, recyclable product

